

Radon Sampling Instructions



Please follow the instructions provided to ensure your sample can be accepted by the laboratory. If you have questions regarding your sample collection, please call us Monday - Friday from 8 am - 6 pm at (775) 355-0202.

Collection Procedure

Radon sampling requires 3 unpreserved VOA vials, a hose, and a clean bucket.

Note: Please do not collect samples on a Friday.

- 1** Slowly run water from hose into (or something smaller) for 5 minutes. Water entering the bucket should be as free as possible of bubbles.
- 2** Fill the VOA vials underwater by placing the hose into the bottle, taking care to release all the air bubbles. Cap tightly underwater.
- 3** Take sample from the bucket, or container, and turn it upside down to check for bubbles. If necessary, repeat sampling until no bubbles are observed.
- 4** Dry sample container.
- 5** Fill out the bottle's label with water repellent ink. Fill out your Chain of Custody (COC) form.
- 6** Deliver samples to your local WETLAB. Samples must be received by the lab at 2°-6°C (35°-42°F) and on ice within 24-28 hours. Note: Please do not collect samples on a Friday.

Sparks • (775) 355-0202
475 E. Greg Street, Ste 119
Sparks, NV 89431

Elko • (775) 777-9933
1084 Lamoille Hwy
Elko, NV 89803

Las Vegas • (702) 475-8899
3230 Polaris Ave. #3 & 4
Las Vegas, NV 89102